

Satellite Dish Installation Guidelines

- Satellite dish to be mounted only in areas marked A or B in diagram and not to exceed 3 feet away from upper corners of balcony area or on top of balcony cover in same locations
- Attachment to any fence, roof or wood siding shall be prohibited
- Wires should be run down corner of balcony wall or into attic space if possible
No wires allowed on exterior wall outside of balcony area
- Any damage caused by neglect or improper installation of the satellite dish shall be the responsibility of the Home Owner
- Upon sale of the property, the satellite dish shall be removed and the associated area restored to the original condition
- All wire to be painted to match stucco

